




**BOSCH**SMS6021/01-EU1
SMS6021ZA/01-ZA1GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
374051 3576
Gebrauchsanweisung
(D,F,GB,I,NL)
51 3779
Montageanweisung
(D,F,GB,I,NL,DK,
E,P,S,N,SF,GR,TR)

- 1) 02 9941
- 2) 02 9029
- 3) 11 7752
- 4) 05 6860
- 5) 02 9944
Set
- 6) 03 0350
40°C
- 7) 02 9005
- 8) —
- 9) 05 6822
- 10) 02 9943
- 11) 02 9945
Set
- 12) 02 9002
Set
- 13) 03 0347
- 14) 02 9012
grün
02 9013
gelb
02 9011
rot

Ident-Nummern-Konstante
3740



**BOSCH**SMS6021/01-EU1
SMS6021ZA/01-ZA1GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740




BOSCH

SMS6021/01-EU1
SMS6021ZA/01-ZA1

GESCHIRRSPÜLGERÄTE
Standgeräte

Ident-Nummern-Konstante
3740



- 1) 01 9202
- 2) 11 0668
- 3) 05 6247