




Gebrauchsanweisung

51 3926
(D,F,GB,I,NL)

Kurzanweisung

51 3927

(D)

Kochbuch

51 3930

(D)

Zubehör:

Einbaurahmen

HZ 67020

Alu-Backblech

HZ 8055

Glaspfanne

HZ 8056


Glasbräter

HZ 9150


1) 03 0681
grün


2) 03 0680
weiss

3) 03 0679



- 1) 03 0671
- 2) 03 0813
- Arretierstift





1) 08 7498
mitbestellen