


**BOSCH**

SMS8052/01-EU1, weiss  
 SMS8052/03-EU2, weiss  
 SMS8052/08-EU3, weiss  
 SMS8052/11-EU4, weiss


GESCHIRRSPÜLGERÄTE  
 Standgeräte



**BOSCH**

SMS8052/01-EU1, weiss  
 SMS8052/03-EU2, weiss  
 SMS8052/08-EU3, weiss  
 SMS8052/11-EU4, weiss

GESCHIRRSPÜLGERÄTE  
 Standgeräte




**BOSCH**

SMS8052/01–EU1, weiss  
 SMS8052/03–EU2, weiss  
 SMS8052/08–EU3, weiss  
 SMS8052/11–EU4, weiss

GESCHIRRSPÜLGERÄTE  
 Standgeräte

Ident – Nummern – Konstante  
 3740 . . . . .




- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889

**BOSCH**

SMS8052/01-EU1, weiss  
SMS8052/03-EU2, weiss  
SMS8052/08-EU3, weiss  
SMS8052/11-EU4, weiss

GESCHIRRSPÜLGERÄTE  
Standgeräte

Ident – Nummern – Konstante  
3740 . . . . .



- 1) 01 9202
- 2) 11 0668
- 3) 05 6247