


SUPER 511 Electronic-VS51105/02-D1, carmesinrot
 SUPER 511 Electronic-VS51105/04-D2, carmesinrot
 SUPER 511 Electronic-VS51108/04-D3, kieferngrün
 SUPER 511 Electronic-VS51108/05-D4, kieferngrün

SUPER 511 Electronic-VS51105/05-D5, carmesinrot
 SUPER 511 Electronic-VS51111/05-D6, ferrarirot
 SUPER 511 Electronic-VS51112/05-D7, mineralgrau
 SUPER 511 Electronic-VS51111/04-D8, ferrarirot

BODENPFLEGEGERÄTE
 Bodestaubsauger



Gebrauchsanweisung
 51 4171
 D1, D2
 (D, NL, F, I, GB)
 51 6281
 D3, D4, D5, D6, D7, D8
 (D, GB, NL, F, I, E, P, GR,
 S, N, SF)

- 1) 05 1183
 D1, D2
 05 4781
 D3, D4, D5, D6, D7, D8
- 2) 02 5536
 D1, D2
 03 1172
 D3, D4, D5, D6, D7, D8
- 3) 05 9771
 D1, D2
 06 7658
 D3, D4
 05 6037
 D5
 06 8566
 D6, D8
 05 9276
 D7
- 4) 08 4013
 02 6608
 D6, D7, D8

Zubehör:

Möbelpinsel
 VX0773, schwarz

Heizkörperbürste
 VZ0683, schwarz

Turbodüse
 VZ470900, schwarz

