





Gebrauchsanweisungen
51 1910
D1
(D,GB,F,I,NL)
51 1911
F1
(F)

1) 05 0642
kompl.

2) 08 4369
D1
08 4370
F1



TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Matsushita	Matsushita	
Typ/Type		FN 73 Q 13 G	FN 66 Q 11 G	
Förderleistung/Delivery/Débit		V 1308	1184	
Anlaufstrom/Starting current/Cour. de démarrage		A 9,4	7,9	
Widerstand/Resistance/Résistance		Ω 11,0	11,8	
		Hi/aux	Ω 40,9	40,1
Temp.-Regler/Thermostat		Ranco		
Typ/Type		K 54		
Reglerstellung/Position		kalt	warm	
Schaltwerte/Switching values/		„ein“	- 24	- 18
Valeurs de commutation		„aus“	- 31	- 24
		(„abtauen“ od.)	„alarm“	- 19
Füllmenge/Fill.quantity/Charge		R12	g	175
Anschlußwert/Conn.load/Puiss. connectée		W	150	120
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		

Pos.	F1	D1		
	Matsushita	Matsushita		
1	14 0358	14 0362		
2				
3	02 6730	02 7666		
4				
5				
6	05 4733			
7	02 6731			
8				
9	05 0166			
10				
11				
12				
13				
14				