



Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
52 6242
(D,GB,F,I,NL)


Montageanleitung
52 2494
(D,GB,F,I,NL,DK,N,SF
SE,TR)

Beistellsatz
26 8449

- 1) 35 5088
- 2) 16 7113
- 3) 16 7112
- 4) 16 8766
- 5) 16 9176



Mat. – Nr. – Konstante
3740



Pos.	V01		
	Danfoss NLY 13K		
1	14 1747		
2			
3	15 1055		
4			
5	15 0760		
6	15 1072		
7			
8	35 5493		
9	05 0166		
10			
11	08 4744		
12	05 6008		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		NLY 13 K		
Förderleistung/Delivery/Débit	l/h	2394		
Anlaufstrom/Starting current/Cour. de démarrage	A	11,3		
Widerstand/Resistance/Résistance	Ha/main/prin. Ω	10,5		
	Hi/aux Ω	11,0		
Temp.-Regler/Thermostat				
Typ/Type				
Reglerstellung/Position				
Schaltwerte/Switching values/	„ein“ $^{\circ}\text{C}$			
Valeurs de commutation	„aus“			
(„abtauen“ od.)	„alarm“			
Füllmenge/Fill.quantity/Charge	R600a g			
Anschlußwert/Conn.load/Puiss. connectée	W	133		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Resistance	Ω			
Leistung/Power/Puissance	W			
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance	Ω			
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance	Ω			
Spannung/Voltage/Tension	V			