





Gebrauchsanweisung
51 4331
(D,GB,F,I,NL,S,SF,E,
P,DK,N)
Montageanweisung
51 4009
(D,GB,F,I,NL,S,SF,E,
P,DK,N)

- 1) 01 9257
2) 02 0605
3) 02 9971
4) 02 9480



Pos.	V01		
	Matsushita	Danfoss	
	S075LKAA	TL 4 A	
1	14 0599	13 1064	
2			
3	03 2034	15 1055	
4			
5		15 1053	
6	05 8457	15 1072	
7			
8	27 0833	27 0833	
9	05 0166	05 0166	
10			
11	08 8893	08 4744	
12	05 6008	05 6008	

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Matsushita	Danfoss	
Typ/Type		S075LKAA	TL 4 A	
Förderleistung/Delivery/Débit	l/h	641	695	
Anlaufstrom/Starting current/Cour de démarrage	A	5,7	8,3	
Widerstand/Resistance/Résistance	Ha/main/prin.	24,4	23,4	
	Hi/aux	39,8	15,5	
Temp.-Regler/Thermostat		Danfoss		
Typ/Type				
Reglerstellung/Position		kalt	warm	
Schaltwerte/Switching values/	„ein“	+4,5	+4,5	
Valeurs de commutation	„aus“	-31,0	-13,5	
	(„abtauen“ od.)	„alarm“		
Füllmenge/Fill.quantity/Charge	R12	g	V01-95	V02-90
Anschlußwert/Conn.load/Puiss. connectée	W	110		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance	Ω			
Leistung/Power/Puissance	W			
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance	Ω			
Schaltuhr/Timer/Minuterie de contact				
Widerstand/Resistance/Résistance	Ω			
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance	Ω			
Spannung/Voltage/Tension	V			