





51 2705
Gebrauchsanweisung
(D,GB,F,I,NL,E)

51 2329
Montageanleitung
(D,GB,F,I,NL,N,S,E)

08 4136
Schraubensatz

08 5059
Befestigungssatz


TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur	Aspera	Matsushita	
Typ/Type	BY 1116 A	D116LRRA	
Förderleistung/Delivery/Débit	l/h	1450	1184
Anlaufstrom/Starting current/Cour. de démarrage	A	9,9	8,75
Widerstand/Resistance/Résistance	Ha/main/prin.	Ω	11,7
	Hi/aux	Ω	37,7
			28,7

Temp.-Regler/Thermostat	Ranco		
Typ/Type	K 59		
Reglerstellung/Position	kalt	warm	
Schaltwerte/Switching values/	+ 4,5	+ 4,5	
Valeurs de commutation	- 31,0	- 13,5	
(„abtauen“ od.)	„alarm“		

Füllmenge/Fill.quantity/Charge	R12	g	180		
--------------------------------	-----	---	-----	--	--

Anschlußwert/Conn.load/Puiss. connectée	W	150		
---	---	-----	--	--

Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance	Ω			
Leistung/Power/Puissance	W			

Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance	Ω			

Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance	Ω			
Spannung/Voltage/Tension	V			

Pos.	I1,E1	I2,E2	
	Aspera	Matsushita	
	BY 1116 A	D116LRRA	
1	14 0405	14 0563	
2	02 6559	05 8506	
3	02 2342		
4	05 1748		
5			
6	05 1746	05 8458	
7	02 2339	02 6731	
8	11 1838	11 1838	
9	05 0166	05 0166	
10			
11	08 5091	08 5182	
12	05 6008	05 6008	