






Gebrauchsanweisung
52 2536
(D,GB,F,I,NL)

Montageanleitung
52 1893
(D,GB,F,I,NL,DK,N,SF,
SE,TR)

Beistellsatz
26 5161



Mat. – Nr. – Konstante
3740



Pos.	Aspera BPK 1084Y		
1	14 2101		
2			
3	18 0819		
4			
5	17 0882		
6	17 0881		
7	16 9319		
8	26 4879		
9	050166		
10			
11	35 4549		
12	05 6008		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES			
Verdichter/Compressor/Compresseur	Aspera		
Typ/Type	BPK 1084Y		
Förderleistung/Delivery/Débit	l/h	1201	
Anlaufstrom/Starting current/Cour de démarrage	A	3,6	
Widerstand/Resistance/Résistance	Ω	29,6	
Hi/aux	Ω	39,1	
Temp.–Regler/Thermostat	Ranco		
Typ/Type	K59		
Regelstellung/Position	kalt	warm	
Schaltwerte/Switching values	"warm"	+4,0	+4,0
Valeurs de commutation	"kalt"	–32,0	–12,0
	"alarm"		
Füllmenge/Fill.quantity/Charge	R600a	*	
Anschlußwert/Conn.load/Puiss. connectée	W	79	
Heizung/Heater/Chauffage			
Widerstand/Resistance/Résistance	Ω		
Leistung/Power/Puissance	W		
Ventilator/Blower/Ventilateur			
Widerstand/Resistance/Résistance	Ω		
Temp.–Regler/Thermostat			
Magnetventil/Magnetic valve/Electrovanne			
Widerstand/Resistance/Résistance	Ω		
Spannung/Voltage/Tension	V		

* siehe Typenschild