


**BOSCH**

HMG8200GB/01-GB1, braun
 HMG8220GB/01-GB2, weiss
 MMG8200GB/02-GB3, braun
 HMG8220GB/02-GB4, weiss

HERDE
 Mikrowellenherde

Ident - Nummern - Konstante
 3740



51 3958
 Gebrauchsanweisung
 (D, F, GB, I, NL)
 51 4298
 Kochbuch
 GB

Zubehör:

Einbaurahmen
 HMZ 8000
 GB1
 HMZ 8020
 GB2
 kratzfeste Abdeckung
 HMZ 8700
 GB1
 HMZ 8720
 GB2
 Alu-Backblech
 HMZ 19 BB
 Glaspfanne
 HMZ 10 GP
 Glasbräter
 HMZ 21 GB




BOSCH

HMG8200GB/01-GB1, braun
HMG8220GB/01-GB2, weiss
MMG8200GB/02-GB3, braun
HMG8220GB/02-GB4, weiss

HERDE
Mikrowellenherde

Ident - Nummern - Konstante
3740




1) 03 0671
2) 03 0813
Arretierstifte

**BOSCH**

HMG8200GB/01-GB1, braun
 HMG8220GB/01-GB2, weiss
 MMG8200GB/02-GB3, braun
 HMG8220GB/02-GB4, weiss

HERDE
 Mikrowellenherde

Ident - Nummern - Konstante
 3740



- 1) 11 4538 Backblech
- 2) 11 4539
- 3) 11 4537 Glasschale
- 02 8732 Anschlag-Backblech
- 4) 03 0698 GB1,GB3
03 0688 GB2,GB4



BOSCH

HMG8200GB/01-GB1, braun
HMG8220GB/01-GB2, weiss
MMG8200GB/02-GB3, braun
HMG8220GB/02-GB4, weiss

HERDE
Mikrowellenherde

Ident - Nummern - Konstante
3740

