



Gebrauchsanweisung
 52 2993
 (D)

1) 02 5876

Zubehör:

- Back- u. Bratrost-
engmaschig
Z1440X0
- Back- u. Bratrostgeköpft
Z1430X0
- Backblech-Alu
Z1330X0
- Backblech-Email
Z1340X0
- Universalpfanne u.
Bratrost
Z1230X0





- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
- V01
- 16 7262
- V02, V03

