






Libro de instrucciones
51 8146
(D,GB,F,E,I,P)





Pos.	ASPERA	ZEM
	B1116Z	GL80AB
1	14 1598	14 1598
2	16 1626	15 4889
3	15 4996	15 4887
4	16 1619	09 6836
5	35 0684	35 0684
6	15 4915	15 4915
7	05 0166	05 0166
8		
9		
10		
11		
12		
13		

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS

Verdichter/Compressor/Compresseur/Compresor Typ/Type/Typo Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux.	ASPERA B1116Z	ZEM GL80AB
---	------------------	---------------

Temp.Reyler/Thermostat/Termostato Typ/Type/Typo Reglerstellung/Position/Conexión Schaltwerte/Switching values/ ..ein/conex.°C Valeurs de commutation/Desconex. ..aus"/descon. (..abtaven' od) ..alarm'	RANCO K54–L1936 MIN. MAX. –17° –23,5° — –29°	
---	--	--

Füllmenge/Fill. quantity/Charge/Carga R134a	g	*	*
---	---	---	---

Anschlußwert/Comm. load/puiss. Connect./Potenc.	W		
---	---	--	--

Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia Leistung/Power/Puissance/Potencia	Ohm W		
---	----------	--	--

Ventilator/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	Ohm		
---	-----	--	--

Magnetventil/Magnetic valve/Electrovanna/Electrovalvula Widerstand/Resistance/Resistencia Spannung/Volare/Tension/Tensión	Ohm V		
---	----------	--	--

Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador			
--	--	--	--

* Siehe Typenschild / See identification plate / Voir plaquette de caractéristiques / Ver plaqueta de características