



Ident-Nummern-Konstante
3740

51 2492
EU1,F1,CH1,DK1
Gebrauchsanweisung
(D,GB,F,I,NL,SF,DK)
51 2304
EU1,F1,CH1,SF1,DK1
Montageanleitung
(D,GB,F,I,NL,SF,DK)



Ident-Nummern-Konstante
3740



Pos.	EU1,F1,CH1, SF1,DK1 Danfoss		
1	14 0380		
2			
3	02 0108		
4			
5	02 7310		
6	05 1413		
7			
8	11 0437		
9	05 0166		
10			
11	11 1243		
12			
13			
14			

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur	Danfoss			
Typ/Type	TL 4 A			
Förderleistung/Delivery/Débit	l/h	702		
Anlaufstrom/Starting current/Cour. de démarrage	A	7,8		
Widerstand/Resistance/Résistance	Ha/main/prin. Ω	23,8		
	Hi/aux Ω	17,0		
Temp.-Regler/Thermostat	Ranco			
Typ/Type	A 59			
Reglerstellung/Position	kalt warm			
Schaltwerte/Switching values/	+ 4 + 4			
Valeurs de commutation	- 26,5 - 11			
(„abtauen“ od.)	„alarm“			
Füllmenge/Fill.quantity/Charge	R12	g	90	
Anschlußwert/Conn.load/Puiss. connectée	W	110		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance	Ω			
Leistung/Power/Puissance	W			
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance	Ω			
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance	Ω			
Spannung/Voltage/Tension	V			