



51 1421/00
D1, F1, GB1
Gebrauchsanweisung
(D,GB,F,I,NL,E)





Pos.	D1, F1, GB1			
	Danfoss			
1	14 0080/44			
2				
3	02 0108/27			
4				
5	02 1361/04			
6	05 1413/06			
7				
8	11 0437/04			
9	05 0166/05/4			
10				
11	11 1243/01			
12				
13				
14				

TECHNISCHE DATEN / TECHNICAL DATA / DONNÉES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss				
Typ/Type		TL 3 A				
Förderleistung/Delivery/Débit	l/h	576				
Anlaufstrom/Starting current/Cour. de démarrage	A	7,2				
Widerstand/Resistance/Résistance	Ha/main/prin.	31,7				
	Hi/aux	17,0				
Temp.-Regler/Thermostat		M + J				
Typ/Type		F 57				
Reglerstellung/Position		kraft warm				
Schaltwerte/Switching values/ Valeurs de commutation	„ein“	+ 4				
	„aus“ („abtauen“ od.)	- 25				
Füllmenge/Fill quantity/Charge		R12	g	90		
Anschlußwert/Conn. load/Puiss. connectée			W	90		
Heizung/Heater/Chauffage						
Widerstand/Resistance/Résistance			Ω			
Leistung/Power/Puissance			W			
Ventilator/Blower/Ventilateur						
Widerstand/Resistance/Résistance			Ω			
Magnetventil/Magnetic valve/Electrovanne						
Widerstand/Resistance/Résistance			Ω			
Spannung/Voltage/Tension			V			