




Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
58 9197 (da)
58 9198 (no)
58 9199 (sv)
58 9200 (fi)

Montageanweisung
58 6500
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HZ331070
Backblech emailliert
HZ331010
Backblech Antihft
HZ332070
Universalpfanne
HZ332010
Universalpfanne
Antihft



