





Mat. - Nr. - Konstante
3740

Gebrauchsanweisung
58 6764
(TR)


Side by Side
Beistellsatz zu KSR

- 1) 18 3821
- 2) 18 3822
- 3) 36 2472
- 4) 36 7363
- 5) 17 2256
- V05
- 6) 42 4801
- V01
- 42 8134
- V02



Mat. – Nr. – Konstante
3740

- 1) 43 1043
- 2) 43 5194
- 3) 43 1044
- 4) 49 1169
- 5) 42 1620
- 6) 42 1625
- 7) 42 1321



Pos.	Danfoss		
	NLE15KTK2		
1	14 2207		
2	17 1519		
3	35 4158		
4	16 5570		
5	16 3427		
6	18 1014		
7	17 1318		
8			
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör	Danfoss		
Typ/Type/Tip	NLE15KTK2		
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi	A		
Widerstand/Resistance/Rezistans Ha/	Ω		
Hi/aux.			
Temp.Reyler/Thermostat/Termostat			
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Acma kapama degerleri	..ein/acma °C		
Valeurs de commutation/Termostat degeri	..aus"/kapama		
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantily/ Dolum miktari	R600	g	*
Anschlusswert/Comm. load/Giris gucu	W		
Heizung/Heater/Rezistans	Ω		
Widerstand/Resistance/Direnc	W		
Leistung/Power/Guc			
Ventilador/Blower/Vantilatör	Ω		
Widerstand/Resistance/Rezistans			
Magnetventil/Magnetic valve/Manyetik valf	Ω		
Widerstand/Resistance/Rezistans	V		
Spannung/Voltage/Gerilim			
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakiniz