





Mat. - Nr. - Konstante  
3740 . . . . .


Gebrauchsanweisung  
59 2644  
(DE,PL)

- 1) 18 3821
- 2) 18 3822
- 3) 36 2472
- 4) 18 4428
- 5) 18 4426



Mat. - Nr. - Konstante  
3740 . . . . .

- 1) 06 0083
- 2) 42 4686
- 3) 16 5557
- 4) 18 8194
- 5) 18 8188
- 6) 41 7890
- 7) 16 6484



| TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS                                                                                                                                                                              |                      |  |  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|--|--|
| Verdichter/Compressor/Compresseur/Compresor<br>Typ/Type/Tipo<br>Förderleistung/Delivery/Debit/Aspiración l/h<br>Anlaufstromm/Starting current/Cour.démarrage/Int.arranque A<br>Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm<br>Hi/aux. | Matsushita<br>DG125E |  |  |
| Klappe Therm./Thermostat/Termostat<br>Typ/Type/Tipo<br>Reglerstellung/Position/Conexión<br>Schaltwerte/Switching values/ ..ein/conex.°C<br>Valeurs de commutation/Desconex. ..aus"/descon.<br>(..abtaven' od) ..alarm'                         |                      |  |  |
| Füllmenge/Fill. quantily/Charge/Carga R600 g                                                                                                                                                                                                   |                      |  |  |
| Anschlusswert/Comm. load/Puiss. Connect./Potenc. W                                                                                                                                                                                             |                      |  |  |
| Heizung/Heater/Chauflage/Resistenc.descong.<br>Widerstand/Resistance/Resistencia KW<br>Leistung/Power/Puissance/Potencia W                                                                                                                     |                      |  |  |
| Ventilador/Blower/Ventilateur/Ventilador<br>Widerstand/Resistance/Resistencia KW                                                                                                                                                               |                      |  |  |

Mat. – Nr. – Konstante  
3740 . . . . .