






Gebrauchsanweisung
59 1085
(DE,FR,ES,PT,NL,GB)

- 1) 17 1312
- 2) 49 0859
- 3) 43 8723
- 4) 18 8196
- 5) 16 5552
- 6) 36 9906
- 7) 42 4824
- 8) 41 8128
- 9) 17 6137
- 10) 36 9820
- 11) 36 6905
- 12) 42 4801
- V01
- 42 8184
- V02
- 13) 43 7167
- V01
- 44 3698
- V02



- 1) 06 0083
V01
17 3747
V02
- 2) 42 0752
- 3) 42 4431
V01
42 0591
V02
- 4) 16 5557
- 5) 49 1361
- 6) 36 3168
- 7) 43 8945
- 8) 49 4865
- 9) 49 4864
- 10) 49 4877
- 11) 18 8194
- 12) 18 8188
- 13) 26 6151
V01
26 6146
V02



Pos.	Mats.		
	DGX110E12		
1	14 3524		
2	42 0376		
3	35 4158		
4	16 3427		
5	49 4670		
6	17 1318		
7	17 1519		
8	18 1014		
9	42 0857		
10	42 6071		
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör		Mats.	
Typ/Type/Tip		DGX110E12TAW	
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi		A	
Widerstand/Resistance/Rezistans Ha/		Ω	
Hi/aux.			
Temp.Reyler/Thermostat/Termostat		Elektronisch	
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Acma kapama degerleri		..ein/acma °C	
Valeurs de commutation/Termostat degeri		..aus"/kapama	
(..abtaven' od)		..alarm'	
Füllmenge/Fill. quantily/ Dolum miktari	R600	g	42
Anschlusswert/Comm. load/Giris gucu	W		
Heizung/Heater/Rezistans			
Widerstand/Resistance/Direnc	Ω		
Leistung/Power/Guc	W		
Ventilador/Blower/Vantilatör			
Widerstand/Resistance/Rezistans	Ω		
Magnetventil/Magnetic valve/Manyetik valf			
Widerstand/Resistance/Rezistans	Ω		
Spannung/Voltage/Gerilim	V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakınız