




Gebrauchs-/
 Aufstellanweisung
 58 4340
 (de) V01,V02
 58 5293 (nl) V03
 59 2140 (de)
 V04,V05
 59 2142 (nl) V06
 59 2144 (ru) V07

Programmtabelle
 58 4341 (de)
 V01,V02
 58 5294 (nl) V03
 59 2141 (de)
 V04,V05
 59 2143 (nl) V06
 59 2145 (ru) V07

1) Blende kompl.
 43 3884 (de) V01
 43 3885 (de) V02
 43 3886 (nl) V03
 44 1009 (de) V04
 44 1010 (de) V05
 44 1011 (nl) V06
 44 1012
 (symbole) V07


Zubehör:


Bodenbefestigung
 WX9756

Entkalker
 46 0038

Verlängerung
 Zulaufschlauch 2,5
 WZ10130

1) 2 x pro Gerät





- 1) 26 3372
- 2) 26 3373
- 3) 16 5983
- 4) 26 3395
- 5) 16 5984
- 6) 48 0138
kompl.
- 8) 16 5978
- 9) 16 7191
- 10) 41 8217

