






Gebrauchsanweisung
58 4688
(de)

Zubehör:

Back- u. Bratrost-
engmasching
Z1440X0
Back- u. Bratrost
gekröpft
Z1430X0
Backblech Alu
Z1330X0
Backblech Email
Z1340X2
Universalpfanne u.
Bratrost
Z1230X2





- 1) 18 2783
- 2) 17 2646
- 3) 18 2612

1) 41 8562

