





Gebrauchsanweisung
52 6100 (de)
52 6101 (en)
52 6102 (fr)
52 6103 (nl)
52 6104 (el)
52 6105 (es)


Montageanweisung
52 4904
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)


Zubehör:
HZ23000
Backblech Alu
HZ23100
Backblech emailliert
HZ23300
Universalpfanne
HZ23400
Kombirost
HZ22500
Grillblech
HZ9150
Glasbräter
HZ23700
Profi-Auszug
HZ25300
Aktiv-Kat.
HZ26000
Metallbräter

1) 01 4254

1) 26 0928
Set







1) 21 5569
Set

