



Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
58 8191 (fr)
59 4003 (es)
59 4004 (pt)


Montageanweisung
58 6500
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HZ341070
Backblech emailliert
HZ341010
Backblech Antihaft
HZ342070
Universalpfanne
HZ342010
Universalpfanne
Antihaft
HZ343070
Profipfanne
HZ333001
Deckel f. Profipfanne
HZ324000
Kombirost
HZ344000
Einlegerost
HZ325070
Grillblech 2-teilig









- 1) 42 2707
- 2) 47 1937
- 3) 42 2755
- 4) 42 2747

