




Mat. – Nr. – Konstante

3740

Gebrauchsanweisung

58 8884 (fr)

Montageanweisung

58 6500

(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:

HZ331070

Backblech emailiert

HZ331010

Backblech Antihft

HZ332070


Universalpfanne


HZ332010


Universalpfanne

Antihft









- 1) 42 2811
- 2) 42 2841
- 3) 42 2707

