





Gebrauchsanweisung
 58 3978
 (de,fr,nl,it)

Montageanleitung
 52 3265
 (de,fr,nl,it)


Kochbuch
 58 3979

Zubehör:

Back- u. Bratrost-
 engmasching
 Z1440X0
 Back- u. Bratrost
 gekröpft
 Z1430X0
 Backblech Alu
 Z1330X0
 Backblech Email
 Z1340X2
 Universalpfanne u.
 Bratrost
 Z1230X2



- 1) 18 2432
- 2) 18 2431
- 3) 18 2398



- 1) 17 2765
- 2) 17 2646
- 3) 18 2427
- 4) 18 2428

1) 16 0916

