





Gebrauchsanweisung
52 3866
(de,en,fr,it,nl,es,pt)

- 1) 17 2345
- 2) 17 2346
- 3) 15 3993
- 4) 15 1674
V01
06 9014
V02



Düsensatz Für:
Erdgas EE20mBar
17 2390
Flüssiggas 28 mBar
15 9769

- 1) 17 3060
- 2) 17 3061
- 3) 17 3062