




Mat. - Nr. - Konstante  
3740 . . . . .


Gebrauchsanweisung  
58 3397 (de)  
58 3402 (pt)  
58 3403 (es)  
58 3406 (pl)  
58 3407 (cs)

Montageanleitung  
52 4061  
(de,en,fr,it,nl,da,sv,no  
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:  
HEZ4000  
Backblech Alu  
HEZ4100  
Backblech emailliert  
HEZ4200  
Backblech (Auszug)  
HEZ4300  
Universalpfanne  
HEZ4400  
Kombirost  
HEZ2400  
Einlegerost  
HEZ4700  
Profi-Pfanne  
HEZ4800  
Profipfanne + Rost  
HEZ4701  
Deckel f. Profipfanne

1) 02 0943  
2) 01 4254






Mat. – Nr. – Konstante  
3740 . . . . .

1) 48 2981  
Set


Zubehoer:  
HEZ2500  
Grillblech  
HMZ21GB  
Glasbraeter  
HEZ6000  
Metallbraeter  
HEZ5052  
Tuergriff Edelstahl  
HEZ5072  
Tuergriff Alu  
HEZ6001  
Backform  
Auslaufsicher





Mat. – Nr. – Konstante  
3740 . . . . .



Mat. – Nr. – Konstante  
3740 . . . . .


1) 17 4791  
Set

2) 21 5852  
Set

3) 21 5832  
Set

21 9378  
V01  
21 9379  
V02  
21 9286  
V03


36 9472  
V01  
36 9476  
V02  
36 9477  
V03



Mat. – Nr. – Konstante  
3740 . . . . .



Mat. – Nr. – Konstante  
3740 . . . . .



28 4913

28 4917